

STEP 1. Remove decal with heat lamp or heat gun.  
Caution, do not heat cold glass it will crack!



*RAPID REMOVER may be used on a wide range of surfaces including, glass, fiberglass, vinyl and painted surfaces that have been properly cured.*

*NOTE: Always test small surface area for compatibility. AVOID*

STEP 2. Spray glue residue with Rapid Remover and let penetrate for 30-60 seconds.



STEP 3. Using a squeegee, scrape to remove glue residue.



STEP 4. Apply by spraying Rapid Remover on a paper towel and wipe surface clean.



STEP 5. Rinse surface with Rapid Tac Application fluid or water. Rapid Remover is water-soluble.